



arlo™

BATTERY WARNINGS AND SAFETY

⚠️ WARNING: Using substandard or rechargeable batteries can cause injury or property damage.

Counterfeit & Inferior-Quality Battery Warning

Do not use counterfeit and/or inferior-quality lithium batteries. Such batteries can develop internal shorts and may pose a fire or burn hazard.

Avoid purchasing batteries from online-auction and other marketplace websites, as these are known sources of counterfeit and/or inferior-quality batteries.

The use of counterfeit and/or inferior-quality batteries could greatly reduce runtime and output performance, damage your Arlo wire-free cameras, and constitute a safety hazard.

Counterfeit and/or inferior-quality batteries that cause damage to your Arlo wire-free camera may void the warranty.

Counterfeit and inferior-quality batteries lack built-in fault and heat protection, which superior quality batteries contain for added safety.

For these reasons, NETGEAR recommends that you use the batteries supplied by NETGEAR with your Arlo wire-free cameras, or batteries from other high quality, established, well-known manufacturers such as Panasonic®, Energizer®, or Duracell®.

Arlo performance claims are based on the use of batteries that initially ship with Arlo wire-free cameras.

Rechargeable Battery Warning

Arlo wire-free cameras have been designed for use with primary, **non-rechargeable** batteries. For the best possible Arlo experience, **WE STRONGLY RECOMMEND** using the non-rechargeable batteries supplied with your Arlo wire-free cameras, or non-rechargeable batteries from other high quality, established, well-known manufacturers such as Panasonic®, Energizer®, or Duracell®.

With the exception of Tenergy Li-Ion RCR123A 3.7V 650mAh rechargeable batteries specifically marked as 'Works with arlo,' the use of any rechargeable batteries with Arlo Wire-Free cameras is expressly and strictly prohibited, as they may pose a fire or burn hazard, or damage your camera.





TO THE EXTENT PERMISSIBLE BY APPLICABLE LAW, NETGEAR DISCLAIMS ALL LIABILITY WHATSOEVER RELATED TO THE USAGE OF RECHARGEABLE BATTERIES IN ARLO WIRE-FREE CAMERAS, INCLUDING WITHOUT LIMITATION, FIRE, DAMAGE TO PROPERTY, BODILY INJURY, AND/OR DEATH. A RECHARGEABLE BATTERY THAT CAUSES DAMAGE TO THE ARLO WIRE-FREE CAMERA MAY RENDER THE NETGEAR WARRANTY NULL AND VOID. YOU ASSUME ANY AND ALL RISKS ASSOCIATED WITH THE USAGE OF RECHARGEABLE BATTERIES IN ARLO WIRE-FREE CAMERAS, INCLUDING WITHOUT LIMITATION, FIRE, DAMAGE TO PROPERTY, BODILY INJURY, AND/OR DEATH.

Safe Battery Handling and Usage

Batteries can EXPLODE, CATCH FIRE, and/or CAUSE BURNS if disassembled, punctured, cut, crushed, short-circuited, incinerated, recharged (disposable cells), or exposed to water, fire, or high temperatures. **To ensure optimal safety and performance:**

- Only use batteries that contain built-in fault and heat protection.
- **DO NOT** use counterfeit or inferior-quality batteries in Arlo wire-free cameras. Use only the batteries supplied by NETGEAR, or those from high quality, established, well-known manufacturers, such as Panasonic®, Energizer®, or Duracell®.
- **DO NOT** use rechargeable batteries.
- **DO NOT** place loose batteries in a pocket, purse, or other receptacle containing metal objects.
- **DO NOT** store batteries with hazardous or combustible material; store in a cool, dry, ventilated area.
- While your Arlo wire-free camera is weatherproof and safe to use outside, **DO NOT** allow the batteries or battery compartment to get wet prior to or during installation.
- **ALWAYS** keep batteries away from children.
- **REPLACE ALL** batteries at the same time with batteries of the same type purchased at the same time from the same manufacturer and **DO NOT** load batteries backwards. **MAKE SURE** the battery compartment is empty and free of any loose debris before inserting batteries. Follow the directions in the quick start guide and/or written on the Arlo wire-free camera.
- Follow local guidelines to dispose of used batteries.

To the extent permissible by applicable law, failure to follow these warnings and/or directions could result in damage to your Arlo wire-free cameras that will not be covered by NETGEAR's warranty.